

# 4smarts

## Bluetooth Speaker SoundForce



Thank You 

for choosing a quality product from 4smarts

## 1 Safety Instructions

### 1.1 General precautions

- Do not drop the product or subject it to violent shocks.
- Have the product repaired by qualified personnel only.

### 1.2 Precautions for electrical products

- Protect the unit from dirt, moisture, overheating, extreme temperatures.
- Do not open the unit or operate it if it's damaged.
- Never use force when plugging in the unit or any adapters.
- Do not operate the unit outside the power limits specified in the technical data.

### 1.3 Battery precautions

- Avoid storage, charging and use in extreme temperatures.
- Recharge the battery regularly (at least quarterly) if stored for a long time.
- Never open, damage, swallow or allow batteries to enter the environment as they contain toxic and environmentally harmful heavy metals.
- In the event of a leaking battery, do not allow the liquid to come into contact with the skin or eyes, rinse with plenty of water and consult a doctor.

## 2 Technical Data

**Bluetooth Version:** V5.3

**IN USB-C:** DC 5V / 350mA


**OUT Watt:** 3W

**Distortion:** <1 %

**Frequency Range:** 80Hz-20kHz

**Support:** TWS Connection, MagSafe

EN




## 3 First Steps

### 3.1 Power on/off

Power on: Press and hold the MFB button for 2 seconds.  
Power off: Press and hold the MFB button for 2 seconds.

### 3.2 Connect

1. After the speaker power on, the working indicator will flash in blue.
2. Turn on the Bluetooth on your phone and search the device, select "4smarts SoundForce" to connect.
3. After connected, working indicator will keep lightning in blue.
4. The speaker will reconnect automatically your phone the next time power on, on condition that the phone's Bluetooth needs to be kept on.



EN

## 4 Function Notes

### Hands-free call

Short press the MFB button to answer an incoming call, press the button again to end the call.

### Pause/Play music

Short press the MFB button to pause music while playing, press the button again to play.

### Volume

Sync the recent volume on your phone, and the default volume is 50% after each power on.

### TWS connection

1. After both speakers are power on, connect one of them to your phone's bluetooth, and the other one do not connect to any device.
2. Double press the MFB button on both speaker, working indicator will flash in blue and white alternately.
3. After the pairing is completed, the left channel speaker working indicator keep lighting blue, and the right channel speaker working indicator keep lighting in white.
4. Each speaker will reconnect automatically TWS and phone after the next power on.

### Charging

1. When the speaker warning low power, it means that battery is going to drained.
2. At the same time, the speaker will reduces the volume automatically to enter power saving state.
3. In this case, please charge the speaker in no time. While charging, the charging indicator keep lighting in orange.
4. Once the charge is completed, the charging indicator will keep lighting in green.

**Note:** If not used for a long time, please charge the speaker at least once every 3 months to extend the battery life.

### Clear connection

1. Triple press the MFB button will clear disconnect the connection with TWS and Bluetooth.
2. The speaker enter waiting pairing state, working indicator flash in blue.

### Save power

The speaker will power off automatically to save power if it stops working for more than 20 min.

EN

## 5 Care and Maintenance

Use only dry, soft cloths for cleaning.

## 6 Warranty

4smarts GmbH accepts no liability or guarantee for damage resulting from improper installation, assembly and improper use of the product or failure to observe the operating instructions and/or safety regulations.

## 7 Disposal notification

 Electrical and electronic devices as well as batteries must not be disposed of with household waste. The consumer is legally obliged to return electrical and electronic equipment as well as batteries at the end of their service life to the public collection points set up for this purpose.

## 8 Service and support

If the product is defective or in case of problems during installation, please consult your dealer or the 4smarts product consulting via: <https://4smarts.com/contact>

### Service Hotline

Monday – Friday: 9am-5am  
+49 (0) 821 20708444  
Email: [customer-service@4smarts.com](mailto:customer-service@4smarts.com)

## 9 Attestation of conformity

Hereby, 4smarts GmbH, declares that this device is in compliance with essential requirements and other relevant provisions of Directive 2014/53/EU. The declaration of conformity may be consulted at [www.4smarts.com](http://www.4smarts.com)

EN

# 4smarts

Thanks for buying our product! We at 4smarts are sure it will serve you well. Follow us on social media for news, customer support and to win great prizes. See you there!



@4smarts\_official



facebook.com/4smarts



linkedin.com/company/4smarts



All listed brands are trademarks of the corresponding companies. Errors and omissions excepted, and subject to technical changes. Our general terms of delivery and payment are applied.

## 1 Sicherheitshinweise

### 1.1 Generelle Vorsichtsmaßnahmen

- Lass das Gerät nicht fallen und setze es keinen starken Erschütterungen aus.
- Lass das Gerät nur von Fachleuten reparieren.

### 1.2 Vorsichtsmaßnahmen für elektrische Produkte

- Schütze das Gerät vor Schmutz, Feuchtigkeit, Überhitzung und extremen Temperaturen.
- Öffne das Gerät nicht und nehme es nicht in Betrieb, wenn es beschädigt ist.
- Wende beim Einstecken des Geräts oder eines Adapters keine Gewalt an.
- Betreibe das Gerät nicht außerhalb der in den technischen Daten angegebenen Leistungsgrenzen.

### 1.3 Vorsichtsmaßnahmen für Batterien

- Vermeide die Lagerung, Aufladung und Verwendung bei extremen Temperaturen.
- Lade den Akku regelmäßig auf (mindestens vierteljährlich), wenn er längere Zeit gelagert wird.
- Batterien niemals öffnen, beschädigen, verschlucken oder in die Umwelt gelangen lassen, da sie giftige und umweltschädliche Schwermetalle enthalten.
- Bei einer auslaufenden Batterie die Flüssigkeit nicht mit der Haut oder den Augen in Berührung kommen lassen, mit viel Wasser ausspülen und einen Arzt aufsuchen.

## 2 Technische Daten

**Bluetooth-Version:** V5.3

**IN USB-C:** DC 5V / 350mA


**OUT Watt:** 3W

**Verzerrung:** <1 %

**Frequenzbereich:** 80Hz-20kHz

**Unterstützt:** TWS-Funktion, MagSafe

DE



## 3 Erste Schritte

### 3.1 Einschalten/Ausschalten

Einschalten: Drücke die MFB-Taste und halte sie 2 Sekunden lang gedrückt.  
Ausschalten: Drücke die MFB-Taste und halte sie 2 Sekunden lang gedrückt.

### 3.2 Anschließen

1. Nachdem der Lautsprecher eingeschaltet wurde, blinkt die Betriebsanzeige blau.
2. Schalte Bluetooth auf deinem Smartphone ein, suche das Gerät und wähle "4smarts SoundForce", um eine Verbindung herzustellen.
3. Nach der Verbindung leuchtet die Betriebsanzeige weiterhin blau.
4. Der Lautsprecher verbindet sich beim nächsten Einschalten automatisch wieder mit deinem Smartphone, vorausgesetzt, dass das Bluetooth des Geräts eingeschaltet bleibt.

DE

## 4 Funktionshinweise

### Freisprecheinrichtung

Drücke kurz die MFB-Taste, um einen eingehenden Anruf anzunehmen, drücke die Taste erneut, um den Anruf zu beenden.

### Musik anhalten/abspielen

Drücke kurz auf die MFB-Taste, um die Musikwiedergabe zu unterbrechen, drücke die Taste erneut, um sie wiederzugeben.

### Lautstärke

Synchronisiere die aktuelle Lautstärke deines Smartphones, die Standardlautstärke beträgt nach jedem Einschalten 50 %.

### TWS-Verbindung

1. Nachdem beide Lautsprecher eingeschaltet sind, verbinde den einen Lautsprecher mit dem Bluetooth deines Smartphones, der andere darf nicht mit einem anderen Gerät verbunden sein.
2. Drücke zweimal die MFB-Taste an beiden Lautsprechern, die Betriebsanzeige blinkt abwechselnd blau und weiß.
3. Nachdem das Pairing abgeschlossen ist, leuchtet die Betriebsanzeige des linken Lautsprechers blau und die Betriebsanzeige des rechten Lautsprechers weiß.
4. Jeder Lautsprecher verbindet sich nach dem nächsten Einschalten automatisch wieder mit TWS und Smartphone.

### Aufladen

1. Wenn der Lautsprecher eine Warnung bei niedriger Leistung ausgibt, bedeutet dies, dass die Batterie entladen ist.
2. Gleichzeitig reduziert der Lautsprecher automatisch die Lautstärke, um in den Energiesparmodus zu wechseln.
3. Lade den Lautsprecher in diesem Fall schnellstmöglich auf. Während des Ladevorgangs leuchtet die Ladeanzeige orange.
4. Sobald der Ladevorgang abgeschlossen ist, leuchtet die Ladeanzeige grün.

**Hinweis:** Wenn du den Lautsprecher längere Zeit nicht benutzt, lade ihn bitte mindestens alle 3 Monate auf, um die Lebensdauer der Batterie zu verlängern.

### Verbindung löschen

1. Durch dreimaliges Drücken der MFB-Taste wird die Verbindung mit TWS und Bluetooth getrennt.
2. Der Lautsprecher geht in den Wartezustand für die Kopplung über, die Betriebsanzeige blinkt blau.

### Strom sparen

Der Lautsprecher schaltet sich automatisch aus, um Strom zu sparen, wenn er länger als 20 Minuten nicht benutzt wird.

DE

## 5 Pflege und Wartung

Verwende zur Reinigung nur trockene, weiche Tücher.

## 6 Gewährleistung

Für Schäden, die durch unsachgemäße Aufstellung, Montage und unsachgemäßen Gebrauch des Produktes oder durch Nichtbeachtung der Bedienungsanleitung und/oder der Sicherheitsvorschriften entstehen, übernimmt die 4smarts GmbH keine Haftung oder Gewährleistung.

## 7 Hinweise zum Umweltschutz

 Elektrische und elektronische Geräte sowie Batterien dürfen nicht über den Hausmüll entsorgt werden. Der Verbraucher ist gesetzlich verpflichtet, Elektro- und Elektronikgeräte sowie Batterien am Ende ihrer Nutzungsdauer an den dafür eingerichteten öffentlichen Sammelstellen abzugeben.

## 8 Service und Support

Sollte das Produkt defekt sein oder Probleme bei der Installation auftreten, wende dich bitte an deinen Händler oder die 4smarts Produktberatung unter: <https://4smarts.com/contact>

### Service-Hotline

Montag - Freitag: 9-5 Uhr

+49 (0)821 20708444

E-Mail: [customer-service@4smarts.com](mailto:customer-service@4smarts.com)

## 9 Konformitätshinweis

Hiermit erklärt die 4smarts GmbH, dass dieses Gerät mit den grundlegenden Anforderungen und anderen relevanten Bestimmungen der Richtlinie 2014/53/EU übereinstimmt. Die Konformitätserklärung kann unter [www.4smarts.com](http://www.4smarts.com) eingesehen werden.

DE