

Samsung

ATIV / Chromebook

- ATIV Smart PC500T
- ATIV Smart PC Pro 700T
- ATIV Tab 3
- ATIV Tab 5
- ATIV Tab 7
- Chromebook Plus
- Chromebook Plus V2
- Chromebook Pro
- Galaxy Chromebook
- Galaxy Chromebook 2

Galaxy Books

- Galaxy Book 2
- Galaxy Book 10.6
- Galaxy Book 12
- Galaxy Book Flex 13
- Galaxy Book Flex α 13.3
- Galaxy Book Flex 15
- Galaxy Book Flex α (Alpha)
- Galaxy Book Pro 360 (13.3")
- Galaxy Book Pro 360 (15.6")
- Galaxy Book2 Pro 360 (13.3")
- Galaxy Book2 Pro 360 (15.6")
- Galaxy Book Go
- Galaxy Book3 360 (13.3")
- Galaxy Book3 360 (15.6")
- Galaxy Book3 Pro 360 (14")
- Galaxy Book3 Pro 360 (16")
- Galaxy Book4 360
- Galaxy Book5 360
- Galaxy Book5 Pro 360

Galaxy Note

- Galaxy Note 2
- Galaxy Note 3
- Galaxy Note 3 Neo
- Galaxy Note 4
- Galaxy Note 5
- Galaxy Note 7
- Galaxy Note 8
- Galaxy Note 8 Ultra
- Galaxy Note 8.0 Tablet
- Galaxy Note 9
- Galaxy Note 10
- Galaxy Note 10 Lite
- Galaxy Note 10+
- Galaxy Note 20
- Galaxy Note 20 Ultra
- Galaxy Note Edge
- Galaxy Note FE (Fan Edition)
- Galaxy Note Pro

Hinweis: Geräteabhängige Sonderfunktionen werden möglicherweise nicht unterstützt.

Note: Device-specific features may not be supported.

Galaxy S

- Galaxy S21 Ultra
- Galaxy S22 Ultra
- Galaxy S23 Ultra
- Galaxy S24 Ultra
- Galaxy S25 Ultra

Notebook

- Notebook 9 Pen 13 (2019)
- Notebook 9 Pen 15 (2019)
- Notebook 9 Pro 13
- Notebook 9 Pro 15
- Series 7 11.6" Slate XE700T1A

Tablets

- Galaxy Tab A10.1 (with S Pen)
- Galaxy Tab A9.7 (with S Pen)
- Galaxy Tab A 8.0 (with S Pen)
- Galaxy Tab A with S Pen 8.0
- Galaxy Tab A Plus
- Galaxy Tab A Plus 8.0
- Galaxy Tab Active2
- Galaxy Tab Active3
- Galaxy Tab Note 10.1 (2014)
- Galaxy Tab S3
- Galaxy Tab S4
- Galaxy Tab S6
- Galaxy Tab S6 Lite
- Galaxy Tab S7 / FE
- Galaxy Tab S7+
- Galaxy Tab S8
- Galaxy Tab S8+
- Galaxy Tab S8 Ultra
- Galaxy Tab S9
- Galaxy Tab S9+
- Galaxy Tab S9 FE
- Galaxy Tab S9 FE+
- Galaxy Tab S9 Ultra
- Galaxy Tab S10
- Galaxy Tab S10 Ultra
- Galaxy Tab S10+

Acer

- Chromebook Tab 10 (D651N-F14MM)
- Switch 7 Black Edition
- Chromebook Spin 11 (R751TN-N14NV)
- Chromebook Spin 13
- Chromebook Spin 311
- Chromebook Spin 511
- Chromebook Spin 512
- Chromebook 500e
- Chromebook 500e (2019)
- ConceptD 9 Pro

Hinweis: Geräteabhängige Sonderfunktionen werden möglicherweise nicht unterstützt.

Note: Device-specific features may not be supported.

- ConceptD 7 Pro
- ConceptD 7 Ezel
- ConceptD 7 Ezel Pro

Lenovo

- ThinkPad 10 (2014)
- ThinkPad Helix
- ThinkPad Helix (2014)
- ThinkPad Tablet 2
- ThinkPad Yoga 12
- ThinkPad X220 Tablet
- ThinkVision LT1423p
- Yoga Book (2016)

Toshiba

- REGZA AT703
- Dynabook V714
- Dynabook KIRA L93
- Dynabook R82
- Portege Z20T-C

Fujitsu**ARROWS Tab**

- QH35/W
- QH55/M
- QH55/S
- Q584/H
- Q584/K
- Q506/MB
- Q506/ME
- Q507/PE
- Q507/P-SP
- Q508/SB
- Q508/SE
- Q509/VE
- Q509/VB
- Q5010/CB
- Q5010/CE
- Q5010/DE
- Q5010/DEG
- Q5010/EEG
- Q5011/GE
- WQ2/D1
- WQ2/E1
- WQ2/E2
- WQ2/F1
- EH
- Q665/L
- Q665/M
- Q616/P
- QH77/M

Hinweis: Geräteabhängige Sonderfunktionen werden möglicherweise nicht unterstützt.

Note: Device-specific features may not be supported.

- Q704/H
- RH77/X
- R726/M
- Q737

QUADERNO

- QUADERNO A4 (Gen.2)
- QUADERNO A5 (Gen.2)
- QUADERNO A4 (Gen.3)
- QUADERNO A5 (Gen.3)

LIFEBOOK

- Q775/K
- T725/K
- T731/D
- T732
- T901
- T902
- T904/H
- TH90-T
- T935/K
- T936

Panasonic

- ToughPad FZ-A1
- ToughPad FZ-G1
- ToughPad FZ-G2
- ToughPad CF-20
- ToughPad CF-H2
- ToughPad CF-33
- TOUGHBOOK CF-19
- TOUGHBOOK CF-C1
- TOUGHBOOK CF-C2

Onyx BOOX

- BOOX Max 2
- BOOX Max 3
- BOOX Max Lumi 1
- BOOX Max Lumi 2
- BOOX Note 1
- BOOX Note 2
- BOOX Note 3
- BOOX Note Air
- BOOX Note Air 3
- BOOX Note Pro
- BOOX Nova3
- BOOX Tab Mini C
- BOOX Ultra

Dell

- Chromebook 5190 2-in-1
- Inspiron Chromebook 14 2-in-1
- Canvas 27

Hinweis: Geräteabhängige Sonderfunktionen werden möglicherweise nicht unterstützt.

Note: Device-specific features may not be supported.

- Latitude 10
-

HP

- Chromebook x360 11 G1 EE
 - Chromebook x360 11 G2 EE
 - Chromebook x360 11 G3 EE
 - Elite x2 1011 G1
 - EliteBook 2470p
 - EliteBook 2760p
 - EliteBook Pro x2 612 G1
 - ZBook x2 G4
-

ASUS

- VivoTab Note 8
 - FT810
 - Eee Note EA800
 - Eee Slate B121
 - Eee Slate EP121
 - Chromebook Flip C213-NA-BW
 - Chromebook Flip C214-MA-BW
-

Ratta (Supernote)

- Supernote A5
 - Supernote A5X
 - Supernote A5X2 Manta
 - Supernote A6
 - Supernote A6X
 - Supernote A6X2 Nomad
-

Amazon

- Kindle Scribe Prime
 - Kindle Scribe (2024)
-

reMarkable

- reMarkable 1
 - reMarkable 2
-

PocketBook

- InkPad X Pro
-

Wacom

- Wacom One

Hinweis: Geräteabhängige Sonderfunktionen werden möglicherweise nicht unterstützt.

Note: Device-specific features may not be supported.