

4smarts

STYLUS PEN

PENCIL PRO 3



THANK YOU ♥
for choosing a quality product from 4smarts

1 Safety Instructions

Please read the complete instructions and all safety instructions carefully before using the appliance for the first time. We accept no liability for damage caused by failure to observe these instructions and the safety instructions.


1.1 General Precautions

- Do not drop the product and use it only in a dry, clean environment.
- Avoid moisture and dust as they may damage the product.
- The item is not a toy and must be kept out of the reach of children.

1.2 Precautions for Batteries

- The unit has a built-in lithium battery and should never be exposed to fire or improperly disposed of.
- Follow all charging instructions and charge the battery at least every 3 months.
- Protect the battery from overheating and do not overcharge it.
- Never expose it to high temperatures and avoid damage and shocks.

2 Product Description



1. USB-C charging port
2. On/Off switch and operating indicator
Green light flashes during the charging process.
Green light remains steady when the charging process is complete.
Green light remains steady during normal operation.
3. Soft-touch coating
4. Durable, interchangeable writing tip
Thread compatible with Apple Pencil tips of the 2nd generation.
5. USB-A to USB-C charging cable - applicable to chargers of any brand.
6. Cable length: 20cm
7. USB-C charging port

3 Technical Details

Material: Aluminum alloy
Input power: 5V
Tip: replaceable
Length: 165mm
Diameter: 8.9mm
Weight: 13g
Battery: Lithium Polymer Battery 130mAh
Charging interface: USB-C
Charging time: about 30 minutes
Compatibility: iPad Air series, iPad Mini series, iPad Pro series, iPad series (2018 and later)

4 Getting Started

Charging:

1. Plug in the Pencil directly into the appropriate power port on your mobile device (tablet/phone/notebook).
2. Use the included USB charging cable and an AC charger to connect the Pencil to a power outlet.


Pairing:

1. Before using the Pencil for the first time, we recommend restarting the iPad.
2. Make sure the system version of iPad is 12.2 or higher.
3. Open the settings on your iPad.
4. Navigate to "Apple Pencil" and uncheck the option "Use with Graffiti" only with Apple Pencil.
5. Go to "Bluetooth" and disable the connection to the original Apple Pencil.
6. Select "Connect I-Pencil pro" in the Bluetooth settings to make a connection.


Open settings > Bluetooth > select "I-Pencil pro" connect.



Turn on settings > Apple pencil > turn of graffiti using Apple pencil only



How to use:
Press the power button to turn on the 4smarts Pencil Pro 3 and start Bluetooth pairing with the iPad.
Once a connection is established, the green LED will light up solid, indicating that the pencil is ready for use.
Note that the 4smarts Pencil Pro 3 also works without a Bluetooth connection. So you can use it even if there is no pairing with the iPad.



If you are connected via Bluetooth, you can check the remaining power of your Pencil Pro 3 in real time on your iPad.

The tip is replaceable and can be removed by turning it counterclockwise.



5 Care and Maintenance

Use only dry cloths for cleaning. The product is not waterproof. Do not clean with water. Do not open the unit and have it repaired only by a specialist.

6 Warranty

4smarts GmbH accepts no liability or warranty for damage resulting from improper installation, assembly and improper use of the product or failure to observe the operating instructions and/or the safety instructions.

7 Disposal Notification



Electrical and electronic devices as well as batteries must not be disposed of with household waste. The consumer is legally obliged to return electrical and electronic equipment as well as batteries at the end of their service life to the public collection points set up for this purpose or to the point of sale.

8 Service and Support

In case of defective products or problems during installation, please contact your dealer or the 4smarts product advisory service at: <http://www.4smarts.com/contact>.

Service Hotline
Monday - Friday: 9 - 17h
+ 49 (0)821 20708444
E-mail: customer-service@4smarts.com

9 Attestation of conformity

Herby, 4smarts GmbH, declares that this device is in compliance with the essential requirements and other relevant provisions of Directive 2014/53/EU. The declaration of conformity may be consulted at www.4smarts.com

1 Sicherheitshinweise

Bitte lies diese Bedienungsanleitung und die Sicherheitshinweise vor der ersten Inbetriebnahme sorgfältig durch. Für Schäden, die durch Nichtbeachtung dieser Anleitung und der Sicherheitshinweise entstehen, übernehmen wir keine Haftung.


1.1 Allgemeine Sicherheitshinweise

- Lass das Gerät nicht fallen und verwende es nur in einer trockenen und sauberen Umgebung.
- Vermeide Feuchtigkeit und Staub, da sie das Gerät beschädigen können.
- Das Gerät ist kein Spielzeug und darf nicht in deine Hände gelangen.

1.2 Vorsichtsmaßnahmen für Akkus

- Das Gerät verfügt über eine eingebaute Lithium-Batterie, die niemals Feuer ausgesetzt oder unsachgemäß entsorgt werden darf.
- Befolge alle Ladeanweisungen und lade den Akku mindestens alle 3 Monate auf.
- Schütze die Batterie vor Überhitzung und überlade sie nicht.
- Setze sie keinen hohen Temperaturen aus und vermeide Beschädigungen und Stöße.

2 Produktbeschreibung



1. USB-C-Ladeanschluss
2. Ein/Aus-Schalter, Betriebsanzeige
Grünes Licht blinkt während des Ladevorgangs
Grünes Licht dauerhaft, wenn der Ladevorgang abgeschlossen ist
Grünes Licht dauerhaft, bei Normalbetrieb
3. Soft-Touch-Beschichtung
4. Verschleißfeste, austauschbare Schreibspitze
Gewinde auch passend für Apple Pencil Spitzen 2. Generation
5. USB-A auf USB-C Ladekabel - anwendbar auf jede Marke von Ladegerät
6. Kabellänge 20cm
7. USB-C Ladeanschluss

3 Technische Daten

Material: Aluminiumlegierung

Eingangsspannung: 5V

Spitze: auswechselbar

Länge: 165mm

Durchmesser: 9,1mm

Gewicht: 13g

Batterie: Lithium-Polymer-Akku 130mAh

Schnittstelle zum Aufladen: USB-C

Ladezeit: ca. 30 Minuten

Kompatibilität: iPad Air Serie, iPad Mini Serie, iPad Pro Serie, iPad Serie (ab 2018)

4 Erste Schritte

Aufladen:

1. Schließe den Pencil direkt an den entsprechenden Stromanschluss deines Mobilgeräts (Tablet/Telefon/Notebook) an.
2. Verwende das mitgelieferte USB-Ladekabel und ein Netzladegerät, um den Pencil an eine Steckdose anzuschließen.


Verbindung:

1. Vor der ersten Verwendung des Stiftes empfehlen wir, das iPad neu zu starten.
2. Stelle sicher, dass die Systemversion des iPads 12.2 oder höher ist.
3. Öffne die Einstellungen auf deinem iPad.
4. Navigiere zu "Apple Pencil" und deaktiviere die Option "Benutzung mit Graffiti nur mit Apple Pencil".
5. Gehe zu "Bluetooth" in den Einstellungen und deaktiviere die Verbindung zum Original Apple Pencil.
6. Wähle "1-Pencil pro Verbinden" in den Bluetooth-Einstellungen, um eine Verbindung herzustellen.

Öffne Einstellungen > Bluetooth > Wähle "1-Pencil pro" verbinden.



Einstellungen > Apple Pencil > Graffiti nur mit Apple Pencil ausschalten




Verwendung:

Drücke die Ein/Aus-Taste, um den 4smarts Pencil Pro 3 einzuschalten und die Bluetooth-Kopplung mit dem iPad zu starten. Sobald eine Verbindung hergestellt wurde, leuchtet die grüne LED dauerhaft auf, was darauf hinweist, dass der Stift einsatzbereit ist. Beachte, dass der 4smarts Pencil Pro 3 auch ohne Bluetooth-Verbindung funktioniert. Du kannst ihn also auch verwenden, wenn keine Kopplung mit dem iPad besteht.



Der Akku des Stifts hält bei voller Ladung ungefähr 10 Stunden.



Die Spitze ist austauschbar und kann durch Drehen gegen den Uhrzeigersinn entfernt werden.

Besteht eine Bluetooth-Verbindung kannst du die verbleibende Energie deines Pencil Pro 3 in Echtzeit auf deinem iPad überprüfen.



5 Wartung und Pflege

Verwende zur Reinigung nur trockene Tücher. Das Produkt ist nicht wasserdicht. Nicht mit Wasser reinigen. Öffne das Gerät nicht und lass es nur von einem Fachmann reparieren.

6 Gewährleistung

4smarts GmbH übernimmt keinerlei Haftung oder Gewährleistung für Schäden, die aus unsachgemäßer Installation, Montage und unsachgemäßem Gebrauch des Produktes oder einer Nichtbeachtung der Bedienungsanleitung und/oder der Sicherheitshinweise resultieren.

7 Hinweise zum Umweltschutz



Elektrische und elektronische Geräte sowie Batterien dürfen nicht mit dem Hausmüll entsorgt werden. Der Verbraucher ist gesetzlich verpflichtet, elektrische und elektronische Geräte sowie Batterien am Ende ihrer Lebensdauer an die dafür eingerichteten, öffentlichen Sammelstellen oder an die Verkaufsstelle zurückzugeben.

8 Service und Support

Bei defekten Produkten oder Problemen während der Installation werde dich bitte an deinen Händler oder an die 4smarts Produktberatung auf: <http://www.4smarts.com/contact>.

Service Hotline

Montag – Freitag: 9-17 Uhr
+ 49 (0) 0821 20708444
E-mail: customer-service@4smarts.com

9 Konformitätshinweis

Hiermit erklärt die 4smarts GmbH, dass sich dieses Produkt in Übereinstimmung mit den grundlegenden Anforderungen und den übrigen einschlägigen Bestimmungen der Richtlinie 2015/35/EU befindet. Die Konformitätserklärung nach der RED Richtlinie findest du unter www.4smarts.com.

4smarts

Thanks for buying our product!

We at 4smarts are sure it will serve you well. Follow us on social media for news, customer support and to win great prizes. See you there!



@4smarts_official



facebook.com/4smarts



@4smarts_germany



All listed brands are trademarks of the corresponding companies. Errors and omissions excepted, and subject to technical changes. Our general terms of delivery and payment are applied.